Cascadia™

Creating Remote Possibilities®

NVRT User's Guide (Ver. 6.3)

- **Analog NVRT: H4, H8, H16**
- **HD-SDI NVRT: HD204, HD408, HD8016**

High Definition H.264

Network Video Recorder Transmitter

About This User's Guide

Before operating the unit, please read this user's guide thoroughly and retain it for future reference.

Precautions


CAUTION
RISK OF ELECTRIC SHOCK
DO NOT OPEN
CAUTION : TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

Explanation of Graphical Symbols

This symbol indicates the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product.

This symbol indicates the presence of “dangerous voltage” within the product’s enclosure that may be of sufficient magnitude to constitute a risk of electric shock, property damage, personal injury, or death.

WARNING

To reduce a risk of fire or electric shock, do not expose this product to rain or moisture.

CAUTION

Changes or modifications not approved by the manufacture will void the warranty of the product.
Using an incompatible battery may increase the risk of fire or explosion.
Replace only with the same or equivalent type battery recommended by the manufacture.
Discard used batteries according to manufacturer’s instructions.

These precautions must be followed for safety reasons.



Warning

- Do not use if the unit emits smoke.
- Do not disassemble the unit.
- Do not place any heavy or sharp objects on the unit.
- Do not place on uneven surface.
- Do not expose to shock or vibration.
- Do not move the unit when the unit is powered on.
- Do not block, and allow dust to accumulate in the air vents.
- Do not restrict airflow of the unit; doing so can damage the unit.
- Installation and servicing should be performed only by qualified and experienced personnel.
- Turn off the power of the NVRT when connecting Cameras, Audio or Sensor Cables.
- The manufacture is not responsible for any damage caused by improper use of the product or failure to follow instructions for the product.
- The manufacture is not responsible for any problems caused by or resulting from the user physically opening the NVRT for examination or attempting to repair the unit.
- The manufacture may not be held liable for any issues with the unit if the warranty seal is removed.

Table of Contents

Product Components 7
Features 8
Specifications: H4, H8, H16 11
Specifications: HD204, HD408, HD8016 13
1. Name, Function and Connection 15
1-1. Front Panel ..... **Error! Bookmark not defined.**
1-2. Rear Panel 15
1-2-1. H4 15
1-2-2. H8 15
1-2-3. H16 16
1-2-4. HD204 16
1-2-5. HD408 17
1-3. Remote Control 18
1-4. Storage Estimation 19
1-5. Booting the NVRT and Basic Time Setting 19
1-6. Setting Daylight Saving Time 20
1-7. Setting NTP (Network Time Protocol) 22
2. Setting up the NVRT 23
2-1. Setup – Main screen and Menu Tree 23
2-2. Setup – Display Mode 27
2-3. Setup – Record Mode 29
2-3-1. Recording Schedules 30
2-4. Setup – Device Mode 32
2-4-1. ALARM-OUT 33
2-4-2 SPOT-OUT Setup 33
2-4-3 CONTROLLER & PTZ Setup 34
2-4-4. Motion Zone Setup 35
2-5. Setup – Storage Mode 36
2-6. Setup – System Mode 37
2-7. Setup – Security Mode 40
2-8. Setup – Network Mode 41
2-8-1. DDNS 43
2-8-2. Network Ports 43
2-8-3. Network Stream 44
2-9. Setup - CONFIG Mode 45

2-10. Quick Setup 47
3. Live, Search and Playback……. ..... ……48
3-1. Live Viewing Screen 48
3-2. SEARCH Screen 50
3-2-1. TIME-LINE Search 51
3-2-2. Event Search 52
3-2-3. Go To First Time 53
3-2-4. Go To Last Time 53
3-2-5. Go To Specific Time 53
3-2-6. Archive Search 53
3-2-7. Log Search 54
3-3. Play Mode 55
4. PTZ Control 56
5. Back Up 57
5-1. Still Image Backup onto USB Flash Drive 57
5-2. Video Backup onto USB Flash Drive 58
5-3. Transferring Still Images or Video from the ARCHIVE List 58
5-4. Playback of Backup Video 59
6. Network Access Using the Single Site Network Viewer 61
6-1. PC Requirements 61
6-2. Installing the Network Viewer 61
6-3. Live Monitoring Mode and Functions 63
6-4. Bi-directional Audio 65
6-5. Remote Search Mode and Functions 66
6-6. PC System Configuration 70
7. Network Access Using the Multi-Sites Network Viewer 73
7-1. Overview 73
7-2. Minimum PC Requirements 73
7-3. Installation of the Program 73
7-4. Live Window 75
7-4-1. Main User Interface 75
7-4-2. Control Buttons 75
7-5. Search and Playback Window 77
7-5-1. Main User Interface 77
7-5-2. Main Control Panel 77
7-6. Setup of UMS Multi Client 79
7-6-1. General 80
7-6-2. Event 80

7-6-3. Record 82
7-6-4. OSD 83
7-6-5. Language 84
7-7. Remote Setup 85
7-7-1. Setting the Display 85
7-7-2. Record 85
7-7-3. Storage 86
7-7-4. Device 86
7-7-5.Upgrade 87
7-7-6. System 87
7-7-7.Network 87
7-8. Operation 88
7-8-1. Addition, Delete, and Modify of NVRT Sites 88
7-8-2. Connect and Disconnect 91
7-8-4. Recording Video on Local PC during Live 93
7-8-5. Local Playback and Remote Playback 94
7-8-6. AVI Backup During Playback 96
8. Network – By a Web-Browser Viewer 98
9. Network Access Using the Mobile Viewer 101
9-1. Installing the Viewer 101
9-2. iUMS for Android Live Monitoring and PTZ Control 101
9-2-1. Live 101
9-2-2.PTZ Control 103
9-3. iUMS for Apple iPhone 103
9-3-1. Live 103
9-3-2.PTZ Control 104
9-3-3. Playback 104
APPENDIX: How to Connect the Network 106
A. How to set the IP address of the NVRT and open TCP port of the router? 106
B. How to access NVRT from a Remote PC? 109
LAN Connection – Using a Switching Hub 109
Internet Connection Using DDNS 111

Product Components

Please make sure the following components are included as specified below.

NVRT Unit	
Client Software CD	
Remote Control	
Battery1.5V (AAA x 2EA)	
User Guide (as PDF on Client Software CD)	
Data Power Cable (x2 EA)	
Mounting Bracket & Screws (x2 EA)	
HDD Mounting Screws	
Power Adaptor (DC12V 5A) & Power Cable (110V or 220V)	
Mouse	

Features

- H.264 Video compression
- HDcctv/HD-SDI Compatible (HD204D / HD408D Model only)
- HDMI 1080P Video Output
- Reliable File System
- 4 Channel Audio Recording: Perfect audio sync. for court evidence.



- Bi-directional Audio over network via Network Client Software, Web-Viewer, CMS, and Mobile Viewer



- Individual Channel Operation

- Motion Detection



- Easy and Simple Graphic User Interface



- Simple Scheduler



- Easy Software Upgrade via USB flash drive or Network software.





- Instant and Convenient Backup via USB Flash Drive, Network or DVD-RW





- Exclusive File Format and AVI Backup
- Time stamp over AVI backup data for court evidence
- S.M.A.R.T. **(**Self-Monitoring, Analysis, and Reporting Technology for HDD)
- Automatic Video Input and Video Loss Detection
- Covert Camera Operation (Provides Enhanced Security)
- Built-in PTZ Camera Control
- Variety of Ways Network Access via Network Client Software, Web-Viewer, CMS, and Mobile Viewer



Specifications: H4, H8, H16

ITEM				H4	H8	H16
Video	Input		Channel	4 channels	8 channels	16 channels
			Input Level	Composite, 1.0Vp-p, 75ohm		
			Signal Format	NTSC/PAL		
			Video Loss Check	Yes		
	Output		VGA	1 VGA		
			HDMI	1 HDMI		
			BNC	1		
			Spot	1		
Audio	Input & Output			4 Line input & 1 Line output		
	Audio Codec			G.711 (ADPCM)		
Alarm	Sensor Input			4 ch (NC/NO Selectable)		
	Alarm Output			1 Alarm out		
Record	Compression			H.264		
	Multi-operation			QuadPlex Live or Playback/Record/Backup/Network		
	Resolution		D1	120fps	120fps	120fps
			Half D1	120fps	240fps	240fps
			CIF	120fps	240fps	480fps
	Recording quality grade			5 Grades		
	Recording Mode			Continuous/Schedule/Motion/Sensor/Manual		
	Motion Detection			Motion detection setup by Grid		
	Recording by channel			Yes		
	Pre Recording			Min. 15 seconds and Max. 20 minutes		
	Post Recording			Min. 10 seconds and Max. 60 seconds		
Display	Frame Rate (/Sec)			NTSC: 30fps/ch / PAL: 25fps/ch		
Playback	Multi-Decoding			1, 4	1, 4, 8	1, 4, 8, 16
	Playback Speed		Single channel	×1/4, 2, 4, 8, 16, 32		
			Multi-channels	x1/4 ~ x32	x1/4 ~ x16	x1/4 ~ x8
	Search Mode			Timeline, Event, Archive, Log		
Storage	HDD		Interface Type	Serial ATA I		
			Capacity of 1 HDD	Max. 2TB		
			Internal HDD #	1 EA (2EA without DVD-RW)		
	ESATA			1		
	Backup		USB Flash drive	Video & Still Image		

		USB External HDD	Video & Still Image
		Network	Video & Still Image
	Serial ATA I port for DVD-RW		1
	USB Port		2 (Front 1, Rear 1)
User I/F	Menu Display		GUI
	Input Method		Remote control, Mouse
Serial port	Console		-
	PTZ control		1 RS-485
	Termination		1
Network	Dynamic DNS		Yes (Free DDNS)
	Network Interface		10/100 base-TX Ethernet (RJ-45)
	Network Streaming		CIF 120fps/100fps
Network Access	Web viewer (1:1)		Live, Search, Backup, PTZF, Remote Setup
	3G Mobile Viewer (1:1)		Live, Search, PTZF
	Single Monitoring SW (1:1)		Live, Search, Backup, PTZF, Remote Setup
	Multi Monitoring SW (1:n)		Live, Search, Backup, PTZF, Remote Setup
Features	DLS (Day Light Saving)		Yes
	Internal Beep		By Alarm, Motion, Video Loss, HDD error
	Multi-Language		Yes
	S/W Upgrade		USB Flash drive, Network
	NTP		Yes
	Watermark		Yes
Power	Power Supply Voltage		DC 12V 5A
Allowable operation temperature			5°C - 40°C, During storage: -10°C - +50°C
Allowable operation humidity			0 - 90 %
Weight	Unit Weight (Gross weight)		4.1Kgs (6.2Kgs) / 9Lbs (13.6Lbs)
Dimension	Unit Dimension (W x H x D)		380mmx340mmx72mm / 14.9” x 13.3” x 28”

Please note that specifications and unit exterior design are subject to change without notification.

Specifications: HD204D, HD408D

ITEM			HD204D / HD408D	
Video	Input	Channel Input Level	4/8CH HD-SDI (720p25/30/50/60, 1080p25/30, 1080i50/60)	
	Output	Main Monitor	HDMI (Max. 1920x1080)	
		Sub Monitor	VGA (Max. 1920x1080)	
		HD-SDI Monitor	N/A	
		CVBS	N/A	
		SPOT	N/A	
Audio	Input		4/8CH Line Input	
	Output		1CH Line and HDMI Output	
	Audio Codec		G.711	
Alarm	Sensor Input		4/8CH, NC/NO Selectable	
	Alarm Out		1/2CH out by Sensor, Motion and Video Loss	
Operation	Multi-operation		QuadPlex: Live or Playback/Record/Backup/Network	
Live	Digital Zoom		Zoom-in of specific area	
	Channel Sequence		3 ~ 60 seconds Auto	
Recording	Compression		H.264	
	Resolution & Recording Frame		720p: Max. 48fps/4CH 1080p: Max. 20fps/4CH	720p: Max. 96fps/4CH 1080p: Max. 40fps/4CH
	Recoding Quality Grade		5 Levels	
	Recording Mode		Continuous, Schedule, Motion, Sensor, Manual	
	Motion Detection		Setup by Grid	
	Pre Recording		Min. 15 seconds and Max. 20 minutes	
	Post Recording		10 ~ 60 seconds	
Playback	Digital Zoom		Zoom-in of specific area	
	Speed	FF	x1/4, x1/2, x2, x4, x8, x16, x32, x64, x128 and x256	
		FR	x2, x4, x8, x16, x32, x64, x128 and x256	
	Search Mode		Timeline, Event, Archive, Log, Specific Time	
Backup	File Format		JPEG/Proprietary Format	
	Media		USB/External HDD/DVD/Network	
	Built-in Viewer		Yes	
Network	Dual Streaming for Live		640x360 and 320x180	
	Playback		H.264 HD	
	Streaming		RTP/RTSP/RTCP	
	Protocols		HTTP, DDNS, NTP, SMTP	

Storage	HDD	Interface	SATA, e-SATA
		Max. Capacity	2TB
		Max. Internal HDDs	2EA
	External Storage		1/2 e-SATA for RAID
	File system		Self-developed, Reliable and Stable File system
	S.M.A.R.T		HDD Error Check and Reporting
User Interface	Menu Display		Graphic User Interface
	Input Method		Front Buttons, IR Remote control, Mouse, Keyboard controller
Serial	POS		1 RS-232C
	PTZ & Controller		1 RS-485
Network	Ethernet		RJ-45, 10/100/1000Base-T, Auto MDI/MDIX
Network Access	Web Viewer		Live, Search/Playback, Backup, PTZF, Remote Setup/Upgrade
	Single-site monitoring software		Live, Search/Playback, Backup, PTZF, Remote Setup/Upgrade
	Multi-sites monitoring software		Live, Search/Playback, Backup, PTZF, Remote Setup/Upgrade
Features	DST (Daylight Saving Time)		Yes
	Internal Beep		By Video Loss, HDD Error
	Multi Language		Yes (more than 20 languages)
	Software Upgrade		By USB, Network Remote Upgrade
	NTP		Yes
	Watermarking		Yes
	3G Mobile		iPhone, Android, Blackberry
General	Operation Condition		5°C - 40°C, During storage: -10°C - +50°C
	Power		DC 12V 5A
	Net Weight (Gross Weight)		4.1Kgs (6.2Kgs) / 9Lbs (13.6Lbs)
	Unit Dimension (W x D x H)		380mm x 340mm x 72mm (14.96" x 13.38" x 2.83")

Please note that specifications and unit exterior design are subject to change without notification.

1. Name, Function and Connection

1-2. Rear Panel

1-2-1. H4



1	Cooling Fan
2	Video Input & Video Output
3	Audio Input
4	HDMI Video Output
5	RS 232 Terminal (For testing purposes)
6	VGA Output
7	eSATA Port
8	Network RS-45 Ethernet Port
9	USB Port
10	RS-485 PTZ Camera control terminal
11	DC12V Power Input

1-2-2. H8



1	Cooling Fan
2	Video Input & Video Output
3	Audio Input
4	HDMI Video Output
5	RS 232 Terminal (For testing purposes)
6	VGA Output
7	eSATA Port
8	Network RS-45 Ethernet Port
9	USB Port
10	RS-485 PTZ Camera control terminal
11	DC12V Power Input

1-2-3. H16



1	Cooling Fan
2	Video Input & Video Output
3	Audio Input
4	HDMI Video Output
5	RS 232 Terminal (For testing purposes)
6	VGA Output
7	eSATA Port
8	Network RS-45 Ethernet Port
9	USB Port
10	RS-485 PTZ Camera control terminal
11	DC12V Power Input

1-2-4. HD204



1	Cooling Fan
2	HD-SDI Video Input
3	Audio Input
4	HDMI Video Output
5	RS 232 Terminal (For testing purposes)
6	VGA Output
7	eSATA Port
8	Network RS-45 Ethernet Port
9	USB Port
10	RS-485 PTZ Camera control terminal
11	DC12V Power Input

1-2-5. HD408



1	HD-SDI Video Input
2	Audio Input
3	RS 232 Terminal (For testing purposes)
4	VGA Output
5	HDMI Video Output RS 232 Terminal (For testing purposes)
6	USB Port
7	RS-485 PTZ Camera control terminal
8	RS-485 Termination
9	Network RS-45 Ethernet Port
10	eSATA Port RS-485
11	DC12V Power Input

1-3. Remote Control



① ID: When a remote control ID number is set in the NVRT, input the NVRT ID number.

② REC: To start and stop manual recording.

③ Number: To select channel (1, 2, 3, & 4) or to enter NVRT ID number.

④ F/REW: During playback - To move the playback position 60 seconds backward.

During pause - To move the playback position 1 frame backward.

⑤ F/ADV: During playback - To move the playback position 60 seconds forward.

During pause - To move the playback position moves 1 frame forward.

⑥ REW: To rewind the footage at 1x, 2x, and 4x speed during playback.

⑦ PLAY/PAUSE: To play or to pause the footage in playback mode.

⑧ FF: To fast forward the footage at 1x, 2x, and 4x speeds during playback.

⑨ Control button: Press to move the menu items or select channel.

⑩ SETUP: To launch SETUP menu.

⑪ SEARCH: To go to the search menu.

⑫ ESC: During setting - To return to previous menu screen.

During playback - To exit from playback

System Lock – To lock a system when pressing ESC button for 5 seconds.

System Unlock – To unlock a system when pressing ESC button for 5 seconds.

⑬ BACKUP: To start operations of backup in live or playback mode. (The same function button as CAPTURE on the front panel of NVRT)

⑭ SEQ: To start auto sequencing of the screen in full screen mode. (Toggle)

1-3. Storage Estimation

Analog NVRT: H4, H8, H8

Recording Condition: 4CH * D1 * 30fps * Continuous					
HDD Capacity	Level 5 (H)	Level 4	Level 3	Level 2	Level 1 (L)
	day(s)	day(s)	day(s)	day(s)	day(s)
250GB	2	3	5	7	11
500GB	5	7	11	15	22
1TB	11	15	22	30	45
2TB	22	30	45	60	90

HD-SDI NVRT: HD204, HD408

4-Channel, Continuous, 1280x720@30fps, Audio On										
HDD Capacity	Level 5 (H)		Level 4		Level 3		Level 2		Level 1 (L)	
	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)
250GB	0	22	1	3	1	12	1	20	2	6
320GB	1	5	1	12	2	0	2	9	3	23
500GB	1	22	2	10	3	5	3	20	4	18
1TB	4	23	5	23	6	14	7	21	9	18
1.5TB	6	0	7	12	10	22	11	21	14	18
2TB	8	1	10	1	13	7	15	22	19	18
4-Channel, Continuous, 640x360@30fps, Audio On										
HDD Capacity	Level 5 (H)		Level 4		Level 3		Level 2		Level 1 (L)	
	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)	day(s)	hour(s)
250GB	1	20	2	7	3	1	3	16	4	13
320GB	2	10	3	0	4	0	4	19	6	23
500GB	3	21	4	20	6	10	7	16	9	13
1TB	8	23	9	22	13	4	15	17	19	13
1.5TB	12	1	15	0	19	21	23	19	29	13
2TB	16	2	20	2	26	15	31	20	39	13

1-5. Booting the NVRT and Basic Time Setting

1. During the first start up, the following message will be displayed.



2. After the system initializing is completed, select the language and set date and time as specified below.





1-6. Setting Daylight Saving Time

If the NVRT is set to Day Light Savings Time and synchronized NTP (Network Time Protocol), Take next steps.

1. Click a mouse-right button or SETUP button on the front panel of NVRT to enter the SETUP mode. The default Password is “1111”.





2. Go to SETUP>SYSTEM>SET DATE & TIME



3. Select DAYLIGHT SAVING.



1-7. Setting NTP (Network Time Protocol)

1. When the NVRT is connected with internet and the NVRT need to be syncronized with NTP (Network Time Protocol), set SETUP>SYSTEM>NTP ON.



2. Select proper TIME ZONE time.



2. Setting up the NVRT

The following sections detail the initial setup of the NVRT.

3-1. Setup – Main screen and Menu Tree

To enter the setup menu, right click on the mouse and select setup from the submenu or press the setup button on the front panel or the remote control.



Figure 3.1.1. Setup Menu Tree



When the NVRT prompts the LOG-IN window, enter the PASSWORD using the virtual keyboard, or the front panel, or the remote control. The factory default password is 1111. It is highly recommended to assign a new password to protect the system. User can assign a new password in SECURITY setup menu.

- DISPLAY
  - OSD
  - OSD CONTRAST
  - SEQUENCE
  - SEQUENCE DWELL TIME
  - CHANNEL
    - NAME
    - COVERT
    - BRIGHTNESS
    - CONTRAST
    - HUE
    - SATURATION
  - VIDEO OUTPUT
- RECORD
  - CHANNEL
    - RESOLUTION
    - FRAME RATE
    - QUALITY
    - RECORDING
    - SENSOR RECORDING
    - PRE RECORD
    - POST EVENT RECORD

        - AUDIO
        - SCHEDULE

- DEVICE
  - ALARM OUT
        - SENSOR IN
        - MOTION ON
        - VIDEO LOSS ON
        - ALARM DURATION
        - ERROR ALARM
  - CONTROLLER & PTZ
        - CHANNEL
        - NAME
        - SPEED
        - ID
  - SPOT OUT
        - SPOT OUT 1
        - SPOT OUT 2
  - CHANNEL
        - MOTION ZONE
        - MOTION SENSITIVITY
  - KEY TONE
  - REMOTE CONTROLLER ID
  - SENSOR
        - TYPE
- STORAGE
  - OVERWRITE
  - DISK FORMAT
  - DISK INFO
  - RECORDING LIMIT
  - S.M.A.R.T
- SYSTEM
  - NVRT-ID
  - DESCRIPTION
  - LANGUAGE
  - DATE FORMAT
  - SET DATE & TIME
        - DAYLIGHT SAVING
        - SET DATE & TIME

- CLIENT ACCESS
- NTP
- SEND EMAIL

- SECURITY
  - USER AUTHENTICATION (ADMIN, NETWORK, USER1, USER2, USER3)
  - USER PASSOWRD
  - PLAYBACK AUTHORITY
- NETWORK
  - PORT
  - NETWORK AUDIO PORT
  - WEB PORT
  - NETWORK TYPE (DHCP, LAN)
  - DDNS
  - NETWORK STREAM
- CONFIG
  - SAVE SETUP TO A USB
  - LOAD SETUP FROM A USB
  - LOAD DEFAULT
  - LOAD FACTORY DEFAULT
  - SOFTWARE UPGRADE
- QUICK SETUP
  - USE QUICK SETUP
    - INPUT DESIRED DAYS
  - CUSTOMER SETTINGS
    - RESOLUTION
    - FRAME RATE
    - QUALITY
    - RECORDING
    - DAYS TO RECORD

2-2. Setup – Display Mode

In the SETUP menu, select the DISPLAY tab. Then, the DISPLAY menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button (◄ ▲ ► ▼) on the remote control and change the value of the menu item.



Figure 3.2.1. Display Mode Setup Screen

Table 3.2.1. Menu Items in DISPLAY Mode Setup

Item	Description
OSD	Enable/disable on-screen-display.
OSD CONTRAST	Set the visibility level of the On Screen Display (OSD) (0~100)
SEQUENCE	Enable/disable sequential display of video in full screen mode.
SEQ-DWELL TIME	Set the dwell time of each, quad or 9 channels display in sequential display mode. (3-60seconds)
CHANNEL	Select a channel for applying the following settings using the mouse or control button on the remote control. Press the right square button to change the setting value of all channels at once. Press SEL button to change the setting value of all channels at once. Left click on the mouse to highlight the setting and double-click if you want to change the value. Once the value has been changed, select OK to confirm the changes. (COVERT, BRIGHTNESS,CONTRAST,HUE,SATURATION)

	COVERT	BRIGHTNESS	CONTRAST	HUE	SATURATION
ALL	OFF	40	40	40	40
1	OFF	40	40	40	40
2	OFF	40	40	40	40
3	OFF	40	40	40	40
4	OFF	40	40	40	40
5	OFF	40	40	40	40
6	OFF	40	40	40	40
7	OFF	40	40	40	40
8	OFF	40	40	40	40
9	OFF	40	40	40	40
10	OFF	40	40	40	40
11	OFF	40	40	40	40
12	OFF	40	40	40	40
13	OFF	40	40	40	40
14	OFF	40	40	40	40
15	OFF	40	40	40	40
16	OFF	40	40	40	40
				OK	CANCEL

NAME	Set the channel name. Press the right square button and set the channel name and select OK using the mouse or the control button (◄ ▲ ► ▼) on the remote control. The name can be made by 10 characters at most.

COVERT	Enable/disable display of the specified video channel in live display mode.
BRIGHTNESS	Change the brightness value of the specified channel. (0~100)
CONTRAST	Change the contrast value of the specified channel. (0~100)
HUE	Change the hue value of the specified channel. (0~100)
SATURATION	Change the saturation value of the specified channel. (0~100)
VIDEO OUTPUT (HDMI/VGA)	Allows user to set monitor output resolution from 720p 50Hz/60Hz, 1080i 50Hz/60Hz, 1080p 50Hz/60Hz

2-3. Setup – Record Mode

In the SETUP menu, select the RECORD tab. Then, the RECORD menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.3.1. Recording Mode Setup Screen

Table 3.3.1. Menu Items in Recording Mode Setup

Menu Item	Description
CHANNEL	Select a channel for applying the following settings using the mouse or the control button on the remote control. Press the right square button to change the setting value of all channels at once. Once you the value has been changed, select OK to confirm the changes. (RESOLUTION, FRAME RATE, QUALITY, RECORDING, PRE RECORD and POST EVENT RECORD)
RESOLUTION	• **Analog NVRT (A1204H, A2408H, A48016H):** Select either CIF, Half D1 and D1 using the mouse or the control button on the remote control. • **HD-SDI NVRT (HD204D, HD408D):** Select either 640 x 360, 1280 x 720, 1920 x 1080 using the mouse or the control button on the remote control.
FRAME RATE	Set the frame rate for the specified channel. The sum of the frame rate values from each channel cannot exceed the maximum frame rates for a specific recording resolution.

	Typical values of the maximum frame rate for video are as follows.

Analog NVRT	CIF	Half D1	D1
H4	120fps/4CH	120fps/4CH	120fps/4CH
H8	240fps/8CH	240fps/8CH	120fps/8CH
H16	480fps/16CH	240fps/16CH	120fps/16CH
HD-SDI NVRT	640 x 360	1280 x 720	1920 x 1080
HD204	120fps/4CH	48fps/4CH	20fps/4CH
HD408	240fps/8CH	96fps/8CH	40fps/8CH

QUALITY	Select the recording quality for the specified channel. LEVEL 1 ~ LEVEL 5 (Allows the user to change the recording QUALITY of the selected CHANNEL)
RECORDING	Assign the recording mode for each channel. Options are: Continuous, By Motion, By Sensor, By Schedule or Disable.
PRE RECORD	Enable/disable pre-event recording. Pre-event recording time is 5 seconds to 20 Minutes.
POST EVENT RECORD	Set the post event recording time duration for the specified channel. (10~60 seconds)
SENSOR RECORDING	Enable setting up to 4 sensors for the specified channel using the mouse or the control button of the remote control.
AUDIO	Enable/disable audio recording for the specified channel.
SCHEDULE	Set the recording schedule. Press SEL to enter the schedule setup screen.

3-3-1. Recording Schedules

To setup a recording schedule, select SCHEDULE in the RECORD menu. Navigate through the menu items using the mouse or the control button on the remote control.

[**Channel**]: Select the specific channel.

[**Setup**]: Set up using the left button of the mouse to section under the specific day and time. It can set the all section under the specific day or time at a time when pressing the specific day or time. It is also possible to set up recording modes of various type using a CONTINUOUS (green), Motion (yellow) and Sensor (red). Left-Click and drag the mouse to change the schedule for more than one timeslot.

[**COPY Schedule]**: To copy the schedule setup from one channel to another, select the channel to copy using the mouse or the buttons on the remote control, and select to channel to copy to and press the select button. Select OK to confirm the changes.





Figure 3.3.2. Schedule Recording Setup Screen

2-4. Setup – Device Mode

In the SETUP menu, select the DEVICE tab. Then, the device menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.4.1. Device Mode Setup Screen

Table 3.4.1. Menu Items in Device Setup Screen

Item	Description
ALARM OUT	Set the sensor, motion, and video loss for each alarm.
CONTROLLER & PTZ	Set the PTZ baud rate, protocol, and ID.
SPOT-OUT	Set the all details for spot monitoring. It supports 2 spot-outs.
CHANNEL	Select specified channel for motion zone setup.
MOTION ZONE	Select either Full Zone or Partial Zone for motion sensing.
MOTION SENSITIVITY	Set the motion sensitivity for the specified channel. Control the motion sensitivity from 1 to 9.
KEY TONE	Enable/disable key tone.
REMOTE CONTROL ID	Select an ID of remote control. 1. Select ID number. 2. Press the same number as ID set in NVRT on the remote control. 3. An icon will be displayed on the Live Screen that corresponds to the remote control ID number.0 The options are from 0 to 99
SENSOR	Select sensor NO from 1 to 4
TYPE	Set the type of sensor for the specified channel. Options are: OFF, N/O (normal open), and N/C (normal closed).

2-4-1. ALARM-OUT



Figure 3.4.2. ALARM-OUT Setup Screen

Table 3.4.2. Menu Item in ALARM-OUT Setup Screen

Item	Description
ALARM OUT	Select an Alarm out number. Available No: 4 CH (1)
SENSOR IN	Enable Alarm Out by Sensor up to 4 Inputs.
MOTION ON	Enable Alarm Out by Camera Motion up to 4 cameras.
VIDEO LOSS ON	Enable Alarm Out by Video Loss up to 4 cameras.
ALARM DURATION	Set the alarm dwell time from 5 to 60 seconds.
ERROR ALARM	Set the error type for the alarm activation. The options are OFF, ALL, HDD ERROR and VIDEO LOSS.

2-4-2 SPOT-OUT Setup



Figure 3.4.3. SPOT-OUT Setup Screen

Table 3.4.3. Menu item in SPOT-OUT Setup Screen

Item	Description
SPOT ON EVENT	Enable/Disable display of the channel when an event is active.
SPOT EVENT **DWELL TIME**	Set the dwell time for the display of the event activated channel. (1-10sec)
SEQUENCE	Enable/disable sequential display of spot channel in full screen. If select ON, spot channel selection screen is displayed.
SEQ-DWEL TIME	Set the dwell time for the spot channel display.(1-10sec)
SPOT CHANNEL	Select a channel for spot monitoring using the mouse or the control button on the remote control and press OK button.

2-4-3 CONTROLLER & PTZ Setup

To control the PTZ functions of the camera, connect a controller to the RS-485 port.

① Connect the RS-485 cables of the PTZ camera to the RS-485 port on the rear panel.



② Press the PTZ menu button. Then PTZ menu screen is displayed as below.



Figure 3.4.4. PTZ Control Setup Screen

Note: For speed dome cameras that support RS-485, connect them directly to the RS-485 port. If the camera is controlled with RS-232C, use a RS-485 to RS-232C signal converter.

On the PTZ control setup screen, you can select or set the protocol type of the camera that is the same as the one installed on the site. If the camera has a specific camera ID, select the camera ID using the mouse or the control button of the remote control.

The following options are available on the PTZ setup screen.

CHANNEL (Channel number that the PTZ is connected to)

NAME (Protocol type)

SPEED (Baud Rate) (19200, 14400, 9600, 4800, 2400)

ID (0-63)

2-4-4. Motion Zone Setup

Select MOTION ZONE using the mouse or the control button on the remote control and select either PARTIAL ZONE or FULL ZONE using the mouse control. The default value is FULL ZONE.

If FULL ZONE is selected, the motion zone grid screen is not displayed. Only set the level of sensitivity for MOTION SENSITIVITY.

FULL ZONE: The motion sensor is active on the whole screen.

PARTIAL ZONE: The motion sensor is active in the set detection frame.

Select the motion detection position using the mouse or the control button on the remote control. Then left click on the mouse or left click and drag the mouse pointer to select or deselect the area. Highlighted area indicates the partial motion detection zone. Press the ESC button or right click on the mouse to return to the previous menu.



Figure 3.4.5. Motion Zone Grid Screen

2-5. Setup – Storage Mode

In the SETUP menu, select the STORAGE tab. Then, the STORAGE menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.5.1. STORAGE Setup Screen

Table 3.5.1. Menu Items in STORAGE Setup Screen

Item	Description
OVERWRITE	When enabled, the NVRT will continue recording and overwrite the oldest existing recorded data once the hard drive is full. When disabled, recording will stop once the hard drive is full.
DISK FORMAT	You will have an option YES or NO for the hard drive format. **Caution**: We recommend that you archive any data that you may need in the future before you format the hard drive.
DISK INFO	Hard drive information.
RECORDING LIMIT	Enable/disable recording limit.
RECORDING LIMIT DAYS	Set the recording limit days. (1- 90 days) When setting to 1 day, the data will be removed by the hour.
S.M.A.R.T	Set the alarm and beep by setting HDD temperature limit. 

2-6. Setup – System Mode

In the SETUP menu, select the SYSTEM tab. Then, the SYSTEM menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.6.1. SYSTEM Setup Screen

Table 3.6.1. Menu Items in SYSTEM Setup Screen

Item	Description
NVRT ID	Set NVRT ID using the mouse or the control button on the remote control. Press OK to apply the NVRT ID.
DESCRIPTION	Press the button to view the system information. (Hardware version, Software version, Storage size, IP address, MAC address and DDNS status and Port Forward Status.)  MODEL NAME N-0440MH SOFTWARE VERSION VER. 3.3.19_10/10/2011 STORAGE SIZE 921 GB IP ADDRESS 192.168.1.80 MAC ADDRESS 00.02.69.05.77.a0 DDNS STATUS 0.0.0.0 (READY) OK
LANGUAGE	Select the display language using the mouse or the control button on the remote control. Once a language is selected, the display language changes.
DATE FORMAT	Select the date display format using the mouse or the control button on the remote control. Options are: (YYYY/MM/DD, MM/DD/YYYY, DD/MM/YYYY, YYYY-MM-DD, MM-DD-YYYY, DD-MM-YYYY)
SET DATE&TIME	Select the display date and time using the mouse or the control button on the remote control and press OK button to set the present date and time.



DAY LIGHT SAVING

Select DAYLIGHT SAVING using the mouse and the control button on the remote control and select the appropriate daylight saving time zone.

If choosing EU or OTHERS, set the applicable conditions.

The options are:

OFF: Daylight saving is turned off.

USA: Applies the USA daylight saving time.

EU: Applies the EU daylight saving time.

- Select the GMT AREA using the control button.
- Set the time difference with the standard time using the control button.

OTHERS: If the time zone is neither USA nor EU, set the start and end date of the daylight saving period.

- Select BEGIN or END using the control button and press the SEL button.
- Select the item using the control button, select the setting value using the control button and press the ESC button to return to SET DATE & TIME setup menu.

CAUTION:

- Do not set the start time to 23:00 for DLS.
- DLS can't be applied if the date of BEGIN and END is the same.

CLIENT ACCESS

Enable/Disable remote access through network client software.

NTP

NTP is an abbreviation for Network Time Protocol, which is for synchronizing the time of the computer systems over variable-latency data networks.



PRIMARY SNTP SERVER: Input the address of the primary NTP time server.

SECONDARY SNTP SERVER: Input the address of the secondary NTP time server.

TIME ZONE: Greenwich Mean Time (GMT) is a term originally referring to mean solar time at the Royal Observatory, Greenwich, London. Because NTP synchronizes with Greenwich Mean Time (GMT) regardless of geography, users must set their own time difference.

CONNECTON MODE: Select NTP time server connection mode.

INTERVAL: Synchronize the clock by hours which is set on the connection period menu.

TIME: Synchronize the clock at the time daily which is set on the connection period menu.

CONNECTION PERIOD: 1~24



SEND EMAIL

TRANSMISSION MODE: Select e-mail attachment format as an image or a video clip of the channel that triggered the alarm when an alarm event is triggered.

IP NOTIFICATION: Enable/disable sending e-mail when the IP address of your NVRT is changed.

EVENT ALARM: Enable/disable sending e-mail reports on the channel that triggered the alarm when an alarm event is triggered.

S.M.A.R.T: Allows the user to set S.M.A.R.T NOTIFICATION ON or OFF

MAIL PORT: Allows the user to set E-MAIL PORT

SECURE OPTION: – NONE, SSL, TLS (Allows the user to select E-MAIL SECURE OPTION)

MAIL TO: Enter the appropriate email address to enable sending e-mail reports using a virtual keyboard.

MAIL SERVER: Enter the appropriate mail server information to enable sending daily e-mail reports using a virtual keyboard.

ID: To set the connection user ID for the mail server using a virtual keyboard. (ex.abcd@abcdefg.com)

PASSWORD: To set the connection password for the mail server using a virtual keyboard.

MAIL FROM: To set the mail address sent to the destination host using a virtual keyboard.

2-7. Setup – Security Mode

In the SETUP menu, select the SECURITY tab. Then, the SECURITY menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.7.1. SECURITY Setup Screen

Table 3.7.1. Menu Items in PASSWRORD Setup Screen

Item	Description
USER AUTHENTICATION	Admin only can access to the menu. **PASSWORD CHECK:** Select either V or nothing for the functions such as **Setup, Playback(PB), PTZ, Record OFF(R/OFF), and Network** Selected Checkbox: The NVRT will ask for a password when the given function is selected for all users. Blank Checkbox: The NVRT will not ask for a password when the given function is selected for all users.
	ADMIN, NETOWRK, USER1, USER2, USER3:

	PASSWORD	SETUP	PB	PTZ	R/OFF	NETWORK
PASSWORD CHECK		☑	☑	☑	☑	☑
ADMIN	1111	☑	☑	☑	☑	☑
NETWORK	1111	☑	☑	☑	☑	☑
USER 1	1111	☑	☑	☑	☑	☑
USER 2	1111	☑	☑	☑	☑	☑
USER 3	1111	☑	☑	☑	☑	☑

OK CANCEL

	Selected Checkbox: The user can access this function. Blank Checkbox: The user can not access this function.
USER PASSWORD	Options are ADMIN, NETWORK, USER1, USER2 and USER3. Select USER PASSWORD using the mouse or the control button on the remote control and press SEL button. Select user type and enter the current password. And, enter a new password, enter the same password again to confirm and select OK. Then the message "PASSWORD CHANGED" is displayed. The factory default password is **1111**.
PLAYBACK AUTHORITY	Allows specific users AUTHORITY OF PLAYBACK per CHANNEL

When the user set this function, the login window will appear. Then, the user can select one of user types (ADMIN, USER1, USER2, USER3) using the mouse or the control button on the remote control. The user can select a password using the mouse or the control button on the remote control. The factory default password is 1111. It is highly recommended to assign a new password to protect the system. User can assign a new password in the SECURITY setup menu.

2-8. Setup – Network Mode

In the SETUP menu, select the NETWORK tab. Then, the network menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.8.1. NETWORK Setup Screen

Table 3.8.1. Menu Items in Network Setup Screen

Item	Description
NETWORK PORT	Set a proper port number for connecting to network. Port number (Default: 5445)
NETWORK AUDIO PORT	Port for audio streaming: NETWORK PORT + 1
WEB PORT	Web Sever Port number (Default: 80)
NETWORK TYPE	Select a type of network connection. Options are: STATIC, DHCP **DHCP:** NVRT will automatically retrieve an IP address from the network. **LAN:** Network information must be manually configured.
DHCP	NVRT will automatically retrieve an IP address from the network.
LAN	IP: Register IP address that is assigned for the NVRT. Gateway: Register Gateway that is assigned for the NVRT. Subnet Mask: Register Subnet Mask that is assigned for the NVRT.
DDNS	Enable/disable using domain name address through DDNS server. "ON" mode, DDNS server name appears for domain registration. DDNS 1: Select ddnscenter.com from three DDNS server. (If a different DDNS server is selected, the NVRT may not connect properly) **DDNS 2**: Select this type when wants to use other general-purpose DDNS Server. **DDNS INTERVAL**: Set the connection interval (5-60 minutes)
NETWORK STREAM	Set the value for network streaming.

2-8-1. DDNS

User can use the function to connect to a network with a domain name. The user can select one type among three DDNS Servers which is supported for free service. The DDNS interval can be set from 5 to 60 minutes. To connect to a network with a domain name, the user must register a MAC address and serial number of the NVRT, and create a unique domain name on http://www.ddnscenter.com.

Select ddnscenter.com from the three DDNS servers. (If you select other DDNS server, the NVRT cannot connect to the DDNS properly.)

Please refer to Appendix: How to connect network section for the detail of the registration.



Figure 3.8.2. Network setup screen – DDNS Server 1

If the user wants to use other general-purpose DDNS Server, select a Sever 2. Then, the user has to input the server name, ID and password using a virtual keyboard.



Figure 3.8.3. Network Setup Screen – DDNS Server 2

2-8-2. Network Ports

When you connect one or more NVRTs to a network through an IP sharing device, each device must have a unique TCP port number for access to each unit from outside the LAN. The IP sharing device must be configured to forward the assigned port to the specific NVRT.

Note: This port number is listed next to the Port menu option in the Network Setup screen. If you plan to access the NVRT units only from within the same LAN, the TCP port does not have to be changed.

Network Access beyond a Router

In order to access the NVRT remotely beyond a router (firewall), the user must open TCP port for command level, live channels and storage channels. The user needs to open 3 ports on the router; the NVRT port 5445, 5446, and the WEB port 80.

If this port is not opened properly, the user can not access NVRT beyond a router.

3-8-3. Network Stream

User can set the frame rate and the bit rate for a network stream for a specific channel. Total frame rate is CIF 120fps/100fps (NTSC/PAL). The bit rate can be set from 128, 256, 384, 512 and 768.

<Note> The network streaming is possible to set up to the recording frame rate of the channel.

	RESOLUTION	FRAME	QUALITY
ALL	CIF	10	LEVEL 5 (H)
1	CIF	10	LEVEL 5 (H)
2	CIF	10	LEVEL 5 (H)
3	CIF	10	LEVEL 5 (H)
4	CIF	10	LEVEL 5 (H)
5	CIF	10	LEVEL 5 (H)
6	CIF	10	LEVEL 5 (H)
7	CIF	10	LEVEL 5 (H)
8	CIF	10	LEVEL 5 (H)
9	CIF	10	LEVEL 5 (H)
10	CIF	10	LEVEL 5 (H)
11	CIF	10	LEVEL 5 (H)
12	CIF	10	LEVEL 5 (H)
13	CIF	10	LEVEL 5 (H)
14	CIF	10	LEVEL 5 (H)
15	CIF	10	LEVEL 5 (H)
16	CIF	10	LEVEL 5 (H)
		OK	CANCEL

Figure 3.8.4. Network Setup Screen – Network Stream

2-9. Setup - CONFIG Mode

In the SETUP menu, select the CONFIG tab. Then, the configuration menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.



Figure 3.9.1. Configuration Setup Screen

Table 3.9.1. Configuration Setup

Item	Description
SAVE SETUP TO A USB	User can save the current configuration (Setting values) of the NVRT to the USB flash drive. Plug in the USB flash on the front panel and press the button to start the saving process. 
LOAD SETUP FROM A USB	User can upload the configuration of the NVRT to another NVRT using the USB Flash drive. Plug in the USB flash drive on the front panel and press the button to start the loading process.



LOAD DEFAULT Press the button to reset the system to the default settings.



(The following settings such as **Language, NVRT ID, Security User Authentication, Security User P/W, Date format, DLS settings, Network settings, HDD overwrite, Limit recording, HDD serial number, and HDD ERROR time** will not be included.)

LOAD FACTORY DEFAULT Press the button to reset the system to the factory default settings.



SOFTWARE UPGRADE Upgrade softeware to the latest version.
After connecting USB flash drive to USB port on the NVRT, click SEARCH. It will automatically find the upgrade file.

2-10. Quick Setup

In the MENU, select the QUICK SETUP tab. Then, the QUICK SETUP menu is displayed as pictured below. Navigate through the menu items using the mouse or the control button on the remote control and change the value of the menu item.

The QUICK SETUP has high priority than other setting values on RECORDING and NETWORK menu. The QUICK SETUP also cannot set to classified according to channel.



Figure 3.10.1. Quick Setup Screen

Table 3.10.1. Quick Setup

Item	Description
USE QUICK SETUP	Select the Checkbox to use the Quick Setup. When user inputs the DESIRED DAYS to record, the system displays a recommended resolution, frame rate, quality and recording type after calculating the capacity of the installed HDD. At that time, the priority is followed by the order of the items; resolution, frame rate, quality and recording type.
CUSTOMER SETTINGS	User can change the setting value such as resolution, frame rate, quality and recording type. By the setting value, the DAYS TO RECORD will change.

3. Live, Search and Playback

3-1. Live Viewing Screen

In the Live screen, video inputs from the cameras are displayed as they are configured in the Display Setup screen. Various On-Screen Display (OSD) symbols, which indicate the status of the NVRT, are described in Table 4.1.1.

Figure 4.1.1. Live Viewing Screen

The following status bar hides automatically and appears again when putting a mouse pointer to the bar.

Table 4.1.1. Status Indicator Icons in Live Viewing Screen

Icon	Description
	Power On/Off button.
	Lock/Unlock Setup button.
	Setup button. Click this button to go to a setup menu.
	Audio button. Click this button to set an audio reception type; Audio Mute, 1 channel or 4 channels. To set just 1 channel, select a specific channel on the live screen at first.

	Search button. Click this button to enter the search menu.
	Backup button. Click this button to do a back-up.
	PTZ button. Opens the PTZ control menu.
	Sequence button. Click this button to use a sequence function.
	Manual Record button. Click this button to enable manual recording.
	Alarm-out function On/Off button. Select this button to disable the alarm.
	Click the split screen icon to change the current split screen mode using the mouse or SEL button.
2009/04/14 17:23:40	Displays the current date and time.
R:A	Remote control ID display. If a remote ID is not set, the message “A(all)” is displayed.
	Displays the amount of recording on the hard disk from 0-99%.
	Indicates that HDD is recycled.
	Continuous recording in progress.
	Manual recording in progress. To set the Manual recording mode, press the Record button on the front panel.
	Motion alarm recording in progress.
	Sensor recording in progress.
	Indicates that the lock is set.
	Audio mute. To set audio mute, press the Audio button on the front panel.
	Single audio display. To set audio single for highlighted channel only, press the Audio button on the front panel.
	To mix audio display, press the Audio button on the left side.
	Indicates that alarm is set. To set the alarm function, press the Alarm button on the front panel.

	Indicates that alarm output is activated.
	Event indicator. When there is an event (motion recording, video loss, HDD fail, S.M.A.R.T), this icon will be highlighted bright.
	Indicates that a network client is connected to the NVRT.
	Indicates that sequencing mode is enabled.

4-2. SEARCH Screen

To enter the search screen menu, select SEARCH menu on the screen using the mouse or press SEARCH icon on live screen.



Figure 4.2.1. Search Screen

There are 7 ways of search menu such as TIMELINE, EVENT, GO TO FIRST TIME, GO TO LAST TIME, GO TO SPECIFIC TIME, ARCHIVE and LOG on the screen.

How to Search Data On the Time-Line Using the Mouse or Front Key Button



① 1 hour moving: 1-hour time bar (Mouse)/ F/REW and F/ADV button (Front Key)

② 5 minute moving: □ **12:00:00** □(Mouse)/ control button □ □(Front Key)

There are 7 ways of search menu such as TIMELINE, EVENT, GO TO FIRST TIME, GO TO LAST TIME, GO TO SPECIFIC TIME, ARCHIVE and LOG on the screen.

3-2-1. TIME-LINE Search

The TIME-LINE search window is used to find the stored video by using the time line bar.





When the Timeline menu is selected, the user can see a calendar which has the recorded data. Select a specific date and time. Use a drag-and-drop function of the mouse control. User can select a specific minutes using a button in the above red box. Press the PLAY button after selecting the specific time. Press the PREV to return to the SEARCH window.

3-2-2. Event Search

The Event Search window is used to find stored video.





Figure 4.2.2. Event Search Screen

When the Event menu is selected, the user can see a calendar which has recorded data. Select a specific date and the event log will be displayed. Press the PLAY button to playback the data or the SAVE button to save the data after selecting the specific data. User can find a data of the specific channel and event using a button in the above red box. Press the PREV to return to the SEARCH window.

3-2-3. Go To First Time

You can access from the oldest recorded data on the NVRT hard drive by selecting GO TO FIRST TIME on the SEARCH window. Press the PREV to return to the SEARCH window.

3-2-4. Go To Last Time

You can access from the last minute recorded data on the NVRT hard drive by selecting GO TO LAST TME on the SEARCH window. Press the PREV to return to the SEARCH window.

3-2-5. Go To Specific Time



Figure 4.2.3. Go To Specific Time

User can search for video data from a specific instance by setting the date and time in the Go To Specific Time menu. Use the mouse or the control button on the remote control to change the date and time value and press the PLAY button after setting. If there are not video data in the set date and time, No Data Exist message displays.

3-2-6. Archive Search

The ARCHIVE Search window is used to find previously stored video or images.



Figure 4.2.4. Archive Search Screen

When the Archive menu is selected, the user can see a calendar which has recording data. Select a specific date and then the archived data will be displayed. Press the Display button to view the still image or the first frame of the selected video, then the user can save the selected data.

3-2-7. Log Search

You can access the LOG list search screen by selecting LOG on the SEARCH window.





Figure 4.2.5. Log Search Screen

When the Log menu is selected, the user can see a calendar which has recording data. Select a specific date and press NEXT button, and then the log data will be displayed. Press the SAVE button to save the data and then the data is saved as a text file format.

3-3. Play Mode

During playback of a recorded event, the mode changes from SEARCH to PLAY. While in PLAY mode, you may return to the SEARCH screen by pressing the X button on the status bar or the ESC button of a remote control.

Figure 4.3.1. PLAY Mode Screen

The following status bar hides automatically and appears again when putting a mouse pointer to the bar.

Table 4.3.1. Button Functions in PLAY Mode

Button	Description
	Return to the previous menu screen, search window, or exit from the Menu.
◄◄	Press to rewind the footage at 1x, 2x and 4x speeds. Reverse playback speed is shown as -1x(normal), -2x (2 times normal) and -4x (4 times normal) at the bottom right of the screen.
--◄	Jump/Step backward. The playback position moves 60 seconds backward.
►/ II	Press to play or pause recorded video.
►--	Jump/Step forward. Playback position moves 60 seconds forward.
►►	Press to fast forward the footage at 1x, 2x and 4x speeds. Playback speed is indicated as +1x, +2x and +4x for normal, twice and 4 times of the regular speed at the bottom right of the screen.
	Press to backup the video.

4. PTZ Control

To control the PTZ functions of the camera, select PTZ menu on the screen using the mouse. Select the item you wish to control the PTZ camera and control them using the mouse or the control button on the remote control. Please refer to the table 5.1. for the control.

Figure 5.1. PTZ Control Screen

Table 5.1. Button Functions in PTZ Control

Item	Description
INITIALIZE	Initialize the PTZ settings of the selected camera.
PAN / TILT	Select PAN/TILT using the mouse or the control button and press SEL button on the remote control. Adjust the tilt (UP/DOWN) / pan (LEFT/RIGHT) position using the mouse or the control button on the remote control.
ZOOM / FOCUS	Select ZOOM/FOCUS using the mouse or the control button and press SEL button on the remote control.

	Adjust the zoom (Mouse Wheel Down or Up/Down button of the remote control)/focus (Mouse Wheel Up or Left/Right button of the remote control) position.
OSD	Select the OSD to enter the menu. Control keys are Right, Left, UP, Down, Select, Far (REW KEY), and Near (FF KEY). Press the ESC button to return to the main menu. Press the PTZ button to escape from the OSD menu.
AUTOSCAN	Press the right key (►) on the control button to start auto scan Press the left key (◄) on the control button to stop auto scan.
PRESET	Select the PRESET and press the left key (◄) on the control button. Then, number input window will appear. Set the number (3 digits) using the number key and press the SEL to set the preset number for the current position. Press the right key (►) on the control button and set the number (3 digits) to go to the preset number.
TOUR	Select the TOUR and press the right key (►) on the control button. Then, number input window will appear. Set the number (1 digit) using the number key and press SEL to make the group number work. Press the left key (◄) on the control button to stop tour. User can set the preset number in the tour group of the OSD menu.
NUMBER	Available only on the TOUR and PRESET menu.
	Press the ESC button to return to the main menu.

- **Preset/ Tour/ OSD/ Auto-scan function are available on the specific model AP8777 and PMA-200.** (Select it in the NAME of PTZ setup menu)

5. Back Up

5-1. Still Image Backup onto USB Flash Drive

Still images can be captured and archived onto a USB flash drive or a hard drive in live mode or while playing back recorded video. In the live mode, press the BACKUP button to launch the archive function or select BACK UP menu on the screen using the mouse.

1. Select a specific channel which wants to backup on live screen.
2. When you press BACKUP button, the archiving screen will display as Figure 6.1.1.
3. Once you press Backup button, the system will start to archive the data to the selected media.



Figure 6.1.1. Still Image Archiving and Backup Screen

NOTICE For a backup using a USB Flash Drive, the file format of the USB flash drive has to be FAT32.

5-2. Video Backup onto USB Flash Drive

Video can be captured and archived onto the USB flash drive or a hard drive while playing back the recorded video.

In playback mode, press the BACKUP button to launch the archiving function.

1. When you press BACKUP button, the NVRT will ask whether to archive a Still Image or Video Clip.
2. If the user selects VIDEO CLIP, the NVRT will ask for the channel, file format and the setting of the archiving duration. If a Huge Backup is selected, the duration is from 1 hour to 24 hours. If the user sets the channel, file format and duration, the NVRT will ask which media you will take for archiving.
3. Once you select the media, the system will start to archive the data to the selected media.



Figure 6.2.1. Video Archiving and Backup Screen

The NVRT will convert the corresponding portion of the video into an AVI file.

5-3. Transferring Still Images or Video from the ARCHIVE List

The stored data in the hard drive can be found in the ARCHIVE list in the SEARCH window.

User can back up still images or video into the storage device from the ARCHIVE list.

1. Select the date to begin searching and navigate through the days using the mouse or the control button on the remote control.
2. Once you have selected the date, press the NEXT button to open the list of stored data.
3. Use the mouse or the control button on the remote control to scroll through the archive list.

4. Select a list of stored events that happened previous or after the current selection.
5. Once the desired event has been selected, press the DISPLAY button to view the still image or the first frame of the selected video.
6. Press the BACKUP button to launch the archiving function in playback mode.
7. Press the CLOSE button to return to the SEARCH window.



Figure 6.3.1. Archive Search Screen

5-4. Playback of Backup Video

- AVI format: AVI format video can be played back using Window Media Player™ or other media player that is compatible with AVI format video.
- NSF format: H.264 format video can be played back using the player (the HD player) that the NVRT copies on USB flash drive with video. This format is only available when the user selects a huge backup.

Three files are copied on USB flash drive.

- H.264 file: H.264 format video file.
- INDEX file: Title file of date and time.
- HD PLAYER: Exclusive video viewer.



6. Network Access Using the Single Site Network Viewer

The NVRT provides a live remote monitoring feature. Remote monitoring requires installation of the network viewer on your PC.

NOTICE
In a high bandwidth network, a maximum of four users can access one NVRT simultaneously. In a low bandwidth network it is recommended that only one user access the NVRT at a time.

7-1. PC Requirements

Minimum PC Requirements

CPU	Intel PentiumIV
	2Ghz
Memory	512MB
VGA	128MB
Resolution	1024x768
Disk Space	1GB
OS	Windows 2000, XP Professional, XP Home, Vista, 7 (NOTE: Not all versions of Vista and 7 are supported)
Network	10/100Base T
Others	Direct X 8.1 or higher

Recommended PC requirements

CPU	Intel Core 2 Duo
	1.8Ghz or higher.
Memory	1GB DDR2 or higher.
VGA	512MB or higher.
Resolution	1024x768
Disk Space	1GB
OS	Windows 2000, XP Professional, XP Home, Vista, 7 (NOTE: Not all versions of Vista and 7 are supported)
Network	10/100/1000Base T
Others	Direct X 9.0 or higher.

6-2. Installing the Network Viewer

1. Insert the provided CD in the CD drive and double-click “UMSMultiClient (XXXX)**.exe**”
2. Select a destination folder and click “Next”.


InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.
Setup will install UMS Client in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\DVR\UMS Client
Browse...
InstallShield
< Back
Next >
Cancel

3. Select the program folder and click “Next”.



4. The setup status screen is displayed.



5. After the installation is completed, **“UMS Multi Client”** icon displays on the desktop screen.

6-3. Live Monitoring Mode and Functions.

Button	Function	Description
	**DATE & TIME**	Displays the current date and time.
	CONNECT/DISCONNECT	Connect/disconnect network connection.
	SEARCH	Switches the live mode to search mode.
	**DISPLAY MODE**	Select a channel and screen display mode.
	PAN/TILT/ZOOM/ FOCUS	Control the PAN/TILT/ZOOM/FOCUS features on the remote camera.

	CAPTURE	Capture a still image from the live screen.
	PLAY/PAUSE	Play/pause live video.
	ALARM	The ON/OFF button of the alarm output of the NVRT. If the NVRT has an alarm output, the button will be indicated red.
	SETUP	Display the setup screen of the network viewer.
	HDD USAGE	NVRT HDD storage Indicator.
	NETWORK BANDWIDTH	Shows the transferred frames and network bandwidth.
	AUDIO	Adjust the volume. The audio can be turned on or off by clicking the audio icon.
	**LOG WINDOW**	Shows the even log, date, and time.

Operations of the display mode of the main screen

- Single channel display - Click the one of channel button or double-click the channel screen.

- QUAD/-screen display - Click the QUAD button to switch to quad-screen display



- Full screen display - Click the maximize button to display only screen and hidden the operation panel.



Image capture of live screen

Still-image of live screen can be captured and saved as a BMP or JPEG file.

1. Click the channel to be captured. Then the selected channel will be highlighted red.
2. Click the CAPTURE button. Then the IMAGE CAPTURE dialog is displayed.



3. Set the SAVE PATH, FILE NAME, and FILE FORMAT and click the OK button to save the captured still image.

6-4. Bi-directional Audio

The UMS Client allows for bi-directional audio between the client and the NVRT unit. The NVRT must have an audio input connected, and the PC must have an audio output.

6-5. Remote Search Mode and Functions

Button	Function	Description
	**DATE & TIME**	Displays the recording time of the data selected on the time bar at the bottom of the main user interface.
	**DISCONNECT**	Disconnect network connection.
	LIVE	Switches the search mode to live mode.
	CAPTURE	Capture a still image from live screen.
	MARK IN	Set the start time for video backup.
	**MARK OUT**	Set the ending time for video backup.

	BACKUP	Backup the selected recorded video as AVI format.
	SEARCH CALENDAR	The calendar shows dates with recorded video in a light blue and the selected date in dark blue.
	**TIMELINE BAR**	The timeline shows recorded data in dark blue on the bar.
	PLAYBACK BUTTON	The playback buttons.
	**DISPLAY MODE**	Select a channel and screen display mode.

Searching and playing video in the remote NVRT

Video recorded in the remote NVRT or Video recorded on the PC can be searched and played back.

1. Connect to the remote NVRT and press the SEARCH button. The live mode will change to the search mode.

- Searching the video recorded in the remote NVRT: Connect to the remote NVRT.
- Searching the video recorded in the PC: Do not connect to the remote NVRT.

2. Select the date to search the video. (NOTE: Dates highlighted blue are only available for playback)

3. Drag the marker on the timeline bar to select the hour. (NOTE: The marker can only be set on the solid blue bar, which indicates the recorded data)



4. Press the PLAY button to begin playback of the recorded data.



Backing up video from the remote NVRT

Video recorded in the remote NVRT can be backed up on the PC HDD as an AVI format or NSF format.

1. Connect to the remote NVRT and play the video recorded in the remote NVRT.
2. Drag the marker on the timeline scale and press the MARK IN button to mark the video backup starting point.



3. Drag the marker on the timeline scale and press the MARK OUT button to mark the video backup ending point. Then the selected marked time to backup will be highlighted in green. Press the BACKUP button to bring up the BACKUP window.

4. In the BACKUP window, select the channels, settings, file path, and the file format. Select the OK button to start the backup process.





- Select Channels: Select channels to backup.
- Start Time / Stop Time: Backup time can be changed.
- File Path: Shows the folder that the backup file is recorded.
- File Format: Select backup file format. (NOTE: File format selection may not be available depending on the firmware version, software version, and the NVRT model)

6-6. PC System Configuration

Click the SETUP button. Then the Setup dialog is displayed as below.



Setting General

Set the Security Option, Save Path, and Miscellaneous.



- **Security Option**: Set a password for security options. When you access any of the selected functions, you will need to enter the password.
- **Save Path**: Specify the location to record for backup and still image capture.
- **Automatic reconnection**: If a user selects this function, the client S/W will automatically try to connect to the previously connected IP address if the network connection is lost.
- **Display network statistics**: If a user selects this function, the client S/W will display network status, Bit rate and Frame rate.
- **Time Format**: Change the mode the Client software displays the time.

Setting Site

The remote NVRTs can be added, modified, and removed.



Setting Event

Set the record path and the size of local disk space for the log files.



- LOG – Select to save event log into ‘log file’.
- ICON – Select to display the event on live video.
- EVENT LIST – Select to show the event in the ‘Event List” window of live mode.

Search and check the recorded log data.



Setting Record

Set the recording conditions and select channels to record.



Select the local disk to use and the amount of disk space you want to allow the program to use for recording.



7. Network Access Using the Multi-Sites Network Viewer

7-1. Overview

The UMS Multi-Client is a multiple site monitoring client software with; video, audio, and alarm signals from the NVRTs over networks. The UMS Multi-Client does not limit the number of NVRT units to register.

The program displays to up 256 live videos on one display and even playback videos window on the same or another display monitor.

On the program, user may control PTZF cameras on the NVRTs. By attaching a microphone and speaker system to devices on site, user may make bi-directional audio communication over the network.

7-2. Minimum PC Requirements

CPU	Intel PentiumIV
	2Ghz
Memory	512MB or Higher is recommended.
VGA	128MB or Higher is recommended.
Resolution	1024x768
Disk space	1GB
OS	Windows 2000, XP Professional, XP Home, Vista (Some versions of Vista has problem in installation. Please contact your vendor for more information.)
Network	10/100Base T
Others	Direct X 8.1 or Higher

Before installing the program, check the PC specifications. The NVRT remote software may not perform correctly if the PC does not meet the minimum requirements.

7-3. Installation of the Program

1. Insert the provided CD in the CD drive and double-click “UMSMultiClient (XXXX)**.exe**”


UMS Multi C (H:)
File Edit View Favorites Tools Help
Back Search Folders
Address H:₩
Go
Name Size Type Date Modified
UMSMClient(090515) 2,794 KB Application 5/21/2009 8:12 AM

2. Select a destination folder and click “Next”.


InstallShield Wizard
Choose Destination Location
Select folder where Setup will install files.
Setup will install UMS Client in the following folder.
To install to this folder, click Next. To install to a different folder, click Browse and select another folder.
Destination Folder
C:\Program Files\DVR\UMS Client
Browse...
InstallShield
< Back
Next >
Cancel

3. Select the program folder and click “Next”.



4. The installation status screen is displayed.



5. After the installation is completed, **“UMS Multi Client”** icon displays on the desktop screen.

7-4. Live Window

When installation is completed, double click the **"UMS Multi Client"** icon on your desktop to start the program.

7-4-1. Main User Interface

8-4-2. Control Buttons

Button	Description
LOCAL PLAYBACK	Click this icon to run a playback window to search and play videos that are recorded in the local PC.
REMOTE PLAYBACK	Click this icon to run a playback window to search and play videos that are recorded in the remote NVRT.

 SITE MANAGEMENT	THUMBNAIL REFRESH: Click this icon to refresh and renew thumbnail image of the connected sites. SITE ADDITION: Click this icon to open 'Site Addition' window. SITE DELETE: Click this icon to delete site from the index window, after disconnect a site. NET FINDER: Select the site from the index window and click this icon to modify the information of specific site.
CONNECT	Click this icon to connect the selected site/sites.
DISCONNECT	Click this icon to disconnect the selected site/sites.
SETUP	Click this icon to setup configuration of UMS MULTI CLIENT.
CAPTURE	Click this icon to capture a still image.
EVENT LIST	Opens list of events logged by the UMS Multi Client.
PAUSE	Click this icon to play/pause live video.
ALARM ON	
RECORD ON	Enable or disable recording of live video to local disk which has set in setup menu.
AUDIO	Use the volume control bar to set the audio level.
MIC	Use the micro phone volume control bar to set the micro phone level.
	User can control PAN/TILT & ZOON/FOCUS. PAN left /right TILT up/down ZOOM in/out FOCUS in/out
 CHANNEL SPLIT	To select the numbers of display channel/channels (Single, quad, 9 channels, and 16 channels) of highlighted site.

 NVRT SITE SPLIT	To select the numbers of NVRT/NVRTs (1 NVRT, 4 NVRTs, 9 NVRTs, 16 NVRTs) on main display screen.

7-5. Search and Playback Window

7-5-1. Main User Interface

You can access to search window by clicking the search icon (Local Playback / Remote Playback) on the upper left of the Live Window.



8-5-2. Main Control Panel

Button	Description
LOCAL PLAYBACK	Click this icon to run a playback window to search and play videos that are recorded in the local PC.
REMOTE PLAYBACK	Click this icon to run a playback window to search and play videos that are recorded in the remote NVRT.

	Directory window shows site/sites that are pre-registered.
CONNECT	Click this icon to connect the selected site/sites.
DISCONNECT	Click this icon to disconnect the selected site/sites.
SETUP	Click this icon to setup configuration of UMS MULTI CLIENT.
CAPTURE	Click this icon to capture a still image.
EVENT LIST	Opens list of events logged by the UMS Multi Client.
MARK IN	Click this icon to set the beginning time for backup of the recorded video in AVI format.
MARK OUT	Click this icon to set the ending time for backup of the recorded video in AVI format.
BACKUP	Click this icon to backup the recorded video in AVI format.
AUDIO	Use the volume control bar to set the audio level.
	To select the numbers of NVRT/NVRTs (1 NVRT, 4 NVRTs, 9 NVRTs, 16 NVRTs) on main display screen.
	To select the numbers of display channel/channels (Single, quad, 9 channels, and 16 channels) of highlighted site.
	To select the channel to playback.
	The calendar shows dates with recorded video in color.
	To display the recorded data of selected channel or all channels on a time line scale.

	To change a timeline scale from 24 hours to 60 minutes. The timeline shows recorded data in color on the bar. You can adjust the timeline scale and move it to the time you wish to playback. Then click the play icon to display the recorded video.
	Playback buttons.

7-6. Setup of UMS Multi Client

Click the setup icon to setup the configuration of UMS Multi Client software. The SETUP window is displayed as below.



8-6-1. General

8-6-1-1. Security Option: Set a password for security options.

Select security options and set a password.

Then when you access any of selected functions, you need to enter the password.

You can also set the save path for capturing and backup.

8-6-1-2. Save Path: Specify the location to save captured still image for Capture and Backup data.

8-6-1-3. Miscellaneous

Automatic reconnection: If a user selects this function, client S/W will automatically try to connect the finally connected IP address, after the network is disconnected.

Always On Top: If a user selects this function, client S/W will display continuously at the very front than other software on the PC.

Time Format: Change the way the Client software displays the time.



8-6-2. Event

Event log can be archived and searched.

8-6-2-1. Archiving Event Log: Specify the location to save event logs and select event to archive.



7-6-2-2. Archiving Event Log: Event log can be searched from selected time.



7-6-3. Record

7-6-3-1. Record Setup: You can set the recording conditions as the following; Always, Event, or Auto record. And you can also select target NVRT/NVRTs and channel/channels.

When you set the recording condition to event, you can set event for motion or alarm with duration.



7-6-3-2. Record Local Storage Setup: You can select the local disk to record and the amount of disk space you want to allow the program to use for recording. You can also select the option to overwrite data or stop recording when the maximum amount of disk space is full.



7-6-4. OSD

You can select the OSD (On Screen Display) to be displayed.



7-6-5. Language

You can select a language to be display.



7-6-6. About

“About” provides network client version information.


Setup
General
Event
Event search
Record
Disk
OSD
About
UMS Multi Client Version 0.0.4 (Build090515)
Copyrigth (C) 2009
This product licensed to :
Warning:this computer program is protected by copyright law and international treaties. Unauthorized reproduction or distribution of this program, or any portion of it, may result in severe civil and criminal penalties, and will be prosecuted to the maximum extent possible under the law.
OK
Cancel

7-7. Remote Setup

The menu settings for the NVRT unit can be set from a PC, via network.

Put the cursor of the mouse on the channel which is connected to the site and press the right. Then the following window is displayed as below. Select the **Remote Setup**.



Then the setup window is displayed. The specified menu screen is displayed on the upper left of the screen.

Setting is the same as with the NVRT menu setting. Refer to the corresponding pages for details on the setting items.

7-7-1. Setting the Display

Select **Display** to set the live video display conditions.



7-7-2. Record

Select **Record** to set the recording conditions.



7-7-3. Storage

Select **Storage** to configure continued recording settings by overwriting the hard disk and the storage period for the recording data.



7-7-4. Device

Select **Device** to set the motion zone, sensor input/alarm output conditions, PTZ control and spot setting conditions.



7-7-5.Upgrade

Select Upgrade for remote firmware upgrade over network.



7-7-6. System

Select **System** to set syst8m and time settings.



7-7-7.Network

Select **Network** to set information about the NVRT network.



7-8. Operation

7-8-1. Addition, Delete, and Modify of NVRT Sites

8-8-1-1. Addition of Sites

1. Click SITE ADDITION button. And then the following window will be displayed as below.



- Model: User has to select the proper NVRT model.

  SNVRT series, H series NVRT

  N series NVRT, HD NVRT

  IP Camera

- Site Name: Input a name that properly describes a site.
- IP Address: Input IP address (Public IP address of a router that NVRT is connected.) or Domain name that is registered at www.ddnscenter.com
- Port No.: Input port number of NVRT. **Default Port Number is "5445".**
- ID: Input ID of NVRT. **Default ID is "admin".**
- Password: Input network password of NVRT. **Default Password is "1111".**

2. Click OK button. And then the registered site is added on the directory window.

7-8-1-2. Delete of Sites

1. Select the site/sites to delete from the directory window.

2. Click SITE DELETE button. And then the selected site/sites is/are deleted.

7-8-1-3. Modify of Sites

1. Select the site/sites to modify from the directory window.

2. Click NET FINDER button. And then the following window will be displayed as below.



3. Click MODIFY button. And then the modified information is applied.



7-8-2. Connect and Disconnect

7-8-2-1. Connect

1. Select site/sites to connect from the directory window.

2. Click CONNECT button, and then site/sites displays/display as connected.

7-8-2-2. Disconnect

1. Select site/sites to disconnect from the directory window.

2. Click DISCONNECT button, and then selected site/sites disconnected.

7-8-3. Still-image Capture During Live

1. Double-click a channel to capture from the display screen. (Otherwise all channels will be captured.).



2. Click CAPTURE button. And then a Capture window will be displayed as below.



3. Set Save path, File Name, and File Format. And then click OK button.
4. Still image is saved as set in Capture window.



7-8-4. Recording Video on Local PC during Live

1. Click SETUP button. And then a setup window will be displayed as below.

2. Select Record and set the values.



3. Select Disk and set the values.



4. Click RECORD ON button. And the color of button is changed.

5. Live video data is recorded as set in Record and Disk setup. These video data can be searched and play-backed with Local Playback.


NC01
File Edit View Favorites Tools Help
Back
Search
Folders
Address C:₩Storage₩NC01
Go
Name Size Type Date Modified
20090608 File Folder 6/8/2009 4:00 PM
20090610 File Folder 6/10/2009 3:16 PM
20090317.ndl 4,275 KB NDL File 3/17/2009 6:24 PM
20090317_0.ndb 102,402 KB NDB File 3/17/2009 5:35 PM
20090317_1.ndb 102,403 KB NDB File 3/17/2009 5:44 PM
20090317_2.ndb 102,402 KB NDB File 3/17/2009 5:52 PM
20090317_3.ndb 73,845 KB NDB File 3/17/2009 6:23 PM

7-8-5. Local Playback and Remote Playback

8-8-5-1. Playback of recorded video on local PC

1. Click LOCAL PLAYBACK button. And then Playback Window will be displayed over the Live Window.



2. Select site/sites to connect from the directory window.

3. Click CONNECT button. And then Green bar displays on Search calendar and timeline scale window.



4. Move the marker on the timeline scale to where there is video data and press the PLAY button.

5. Video data that is recorded on local PC will be play-backed.

7-8-5-2. Playback of Recorded Video on Remote NVRT

1. Click REMOTE PLAYBACK button. And then Playback Window will be displayed over the Live Window.



2. Select the site to connect from the directory window.

3. Click CONNECT button. And then Green bar displays on Search calendar and timeline scale window.



4. Move the marker on the timeline scale to where there is video data and press the PLAY button.



5. Video data that is recorded on the remote NVRT is play-backed.

7-8-6. AVI Backup During Playback

You can back up the recorded videos in AVI format during playback.

1. Double-click the target channel to backup.

2. Select the beginning time by using the search calendar and timeline scale bar.



3. Click MARK IN button on the timeline scale to select the beginning point of the backup.



4. Click MARK OUT button on the timeline scale to select the ending point of the backup. Then, the selected starting point and the ending point on the timeline scale bar will be marked in green.



5. Click BACKUP. And then the BACKUP window will be displayed as below.



6. You can also set the beginning time and ending time on this window. After selecting a channel for backup, click the OK button. The backup will begin.



7. AVI video data is recorded as set in AVI Backup window. AVI format video can be played back by Window Media Player™ or other media player that is compatible with AVI format video.

Notice

When backing up as a NSF format, the user can playback using the NVRT Player, which is downloaded into the USB flash drive or the DVD-R with the backup data.

8. Network – By a Web-Browser Viewer

The NVRT provides a live remote monitoring feature by web-browser viewer. (NOTE: Web-Brower is only available for Internet Explorer)

1. Check the IP address of the NVRT from SETUP>SYSTEM>DESCRIPTION>IP ADDRESS.



2. Input the IP address or Domain name address that you pre-registered on www.ddnscenter.com .

3. Click this bar. Then the dialog box is displayed.

4. Click “Install” to download and install the Active-X control.

Internet Explorer - Security Warning
Do you want to install this software?
Name: WebViewer
Publisher:
More options
Install
Don't Install
While files from the Internet can be useful, this file type can potentially harm your computer. Only install software from publishers you trust. What's the risk?

5. The Web Browser Viewer will be displayed as below after the Active-X installation.



6. Click the CONNECT button on the Left upper corner of web-viewer. Then "Connect" dialog is displayed. Enter IP address (or Domain name address that you pre-registered on www.ddnscenter.com, Port number and Password and click "Connect"



- Site Name: Input a name that properly describes a site.
- IP Address: Input IP address (Public IP address of a router that NVRT is connected.) or Domain name that is registered at www.ddnscenter.com

- Port No.: Input port number of NVRT. **Default Port Number is “5445”.**
- ID: Input ID of NVRT. **Default ID is “admin”.**
- Password: Input network password of NVRT. **Default Password is “1111”.**

7. Then the cameras connected to the NVRT are displayed on the screen.



8. SETUP: The menu settings for the NVRT unit can be set from a PC, via network. Refer to the detail of Remote Setup description of UMS Multi Client.

9. Network Access Using the Mobile Viewer

9-1. Installing the Viewer

1. Enter the Apple App Store (For Apple iPhone/iPad Users) or the Android Market (For Android Phone/Tablet users)

2. Search “iUMS” in the App Store© or the Android Market©

3. Install the “iUMS” app. Then iUMS icon will be display on the phone.




Notice

3G Data Usage applied without Wi-Fi connection. Please check with your Phone Carrier.

9-2. iUMS for Android Live Monitoring and PTZ Control

9-2-1. Live

1. Open the installed “iUMS” App and select the Live Preview. Then click the menu button of the phone to add a remote device.



2. Select the registered device and select the channels to monitor up to 4 channels. Then press SELECT button.

3. The app will display the selected channel(s). Double tap the channel screen to switch 1 channel display to 4 channels split display or vice versa.



9-2-2.PTZ Control

To control the PTZ function of the camera, tap the channel screen, then the channel name will be Yellow. Using PTZ menu icons on the screen, control PTZF control.



9-3. iUMS for Apple iPhone

9-3-1. Live

1. Open the installed "iUMS" App and select the Live Preview. Then click the menu button of the phone to add a remote device.
2. Select the registered device and select the channels to monitor up to 4 channels. Select Mode as 'Live' Live and click 'Connect' .

3. The app will display the selected channel(s). Double tap the channel screen to switch 1 channel display to 4 channels split display or vice versa.



9-3-2.PTZ Control

To control the PTZ functions of the camera, tap the menu button. Then PTZ menu icons will display. Using the PTZ icon on the screen, control PTZF control.



10-3-3. Playback

1. Select the registered device and select the channels up to 4 channels to search and playback. Select Mode as 'Playback' Playback and click 'Connect' . Then the search window will display.



2. Select the date, hour, minute, AM/PM and click 'Connect & Play' .



3. The app will display the selected channel(s). Double tap the channel screen to switch 1 channel display to 4 channels split display or vice versa.



4. Tap the menu button. Then Playback menu icons will display.



APPENDIX: How to Connect the Network

A. How to set the IP address of the NVRT and open TCP port of the router?

The port forwarding steps will vary depending on the brand and model of the router. Port Forwarding is required to access the NVRT remotely. (NOTE: Please check your router's User's Manual for detailed instructions on Port Forwarding)

Connect network cable between NVRT and Router or ADSL modem.



1. Default network setting on NVRT are
   - Port: 5445
   - WEB Port : 80
   - Network : DHCP
2. From a PC connected to the same Router as the NVRT, select start>run>cmd to open the command prompt. In the command prompt, type "ipconfig" to find the following information; IP Address, Subnet Mask, and Default Gateway.




C:₩WINDOWS₩system32₩cmd.exe
C:₩>ipconfig
Windows IP Configuration
Ethernet adapter Local Area Connection:
Connection-specific DNS Suffix . :
IP Address. . . . . : 192.168.0.101
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.0.1
C:₩>

3. Open the default NVRT port 5445 and the Default Web Port 80 on the router if the NVRT's NETWORK TYPE is set to DHCP. If the NVRT's NETWORK TYPE is set the LAN, input the following information in the NVRT; IP Address, Subnet Mask, and Default Gateway.



Open your web browser. Enter the router IP address in the address bar and press enter. (NOTE: The routers gateway will vary depending on the brand and model of the router, please refer to your routers user's manual)

4. Enter the user name and password and press the **OK** button. (NOTE: The username and password will vary depending on the brand and model of the router, please refer to your routers user's manual)

5. Select the Port Range Forwarding tab.



6. Enter the each field.
   i. Application: Enter a description of the NVRT (Example: store1)
   ii. Start: Enter the first number of the port you need to port forward (Example: 5445)
   iii. End: Enter the last number of the port you need to port forward (Example: 5445)
   iv. Protocol: Select Both.
   v. IP address: Enter the IP address of the NVRT on SETUP>NETWORK>LAN>IP ADDRESS.
   vi. Enable: Check the enable box.
7. Select the Save settings button located on the bottom of the window. Then Port forwarding is finished.

The site below shows steps for port forwarding for specific router models.
http://www.portforward.com/english/routers/port_forwarding/routerindex.htm

B. How to access NVRT from a Remote PC?

LAN Connection – Using a Switching Hub

Connect an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN Cable) from the system to a router (hub)



1. Run the pre-install the network client software on the supplied CD.
2. Check the IP address from SETUP>SYSTEM>DESCRIPTION of NVRT.



3. Run network client software and click button.



4. Input Site Name, Site Address (IP address), Port No., and Password on the connect window.

- Site Name: Input a name that properly describes a site.
- IP Address: Input IP address (Public IP address of a router that NVRT is connected.) or Domain name that is registered at www.ddnscenter.com
- Port No.: Input port number of NVRT. **Default Port Number is "5445".**
- ID: Input ID of NVRT. **Default ID is "admin".**
- Password: Input network password of NVRT. **Default Password is "1111".**

5. And select the OK button. Then, press button after checking the left check box.

Internet Connection Using DDNS

Connect an Ethernet cable (10BASE-T/100BASE-TX CAT 5 LAN Cable) from the system to a router (hub)



1. Go to SETUP>NETWORK. Set NETWORK TYPE as DHCP or LAN and set the DDNS SERVER to ON. **And select ddnscenter.com on DDNS1. (If a different DDNS server is selected, the NVRT will not communicate with the DDNS server)**



2. Open the TCP port 5445 and the Web Port 80 in the router. (Refer to A. How to set IP address of the NVRT and open TCP port of the router?)
3. Confirm the Mac address and Serial Number from the NVRT. (NOTE: The Mac Address and the Serial Number of the NVRT can be found on the NVRT unit's label)
4. Open the web browser and log on http://www.ddnscenter.com

- MAC Address: Input the Mac address of the unit (EX. 0002690XXXXX) without any spaces.
- Serial Number: Input the Serial Number of the unit (EX. N1640Mxxxxxxxxx) without any spaces.
- Domain Name: Input Domain Name for your NVRT system (NOTE: Letters A-Z, numbers 0-9 are only applicable. Do not enter symbols or spaces)

5. Click the DUPLICATION CHECK button to see if the domain name is available.
6. If you see the screen “You can use the Domain name you entered” then click RETURN and click REGISTER button to complete the registration.
7. Run the pre-install the network client software on the supplied CD.
8. Click SITE ADDITION button to add the NVRT.



- Site Name: Input a name that properly describes a site.
- IP Address: Input IP address (Public IP address of a router that NVRT is connected.) or Domain name that is registered at www.ddnscenter.com
- Port No.: Input port number of NVRT. **Default Port Number is “5445”.**
- ID: Input ID of NVRT. **Default ID is “admin”.**
- Password: Input network password of NVRT. **Default Password is “1111”.**

9. Press CONNECT button after checking the left check box of the site that you will access.